



Paradigm Rocket Motor
Propellant inhibitors & spacer

Rod-grain spacer
(flat development)

- Notes:
1. Dimension is approximate. Actual dimension is dependant upon actual thickness of material.
 2. Coat entire hatched surface with adhesive just prior to rolling into tube form. Use white carpenter glue diluted with 30% water.
 3. Lightweight nylon fabric bonded to spacer with 3M Super 77 spray adhesive, or equivalent.