

## Notes:

1) Anomaly warnings

WARN 1 – indicates that relay contacts are closed when non-activated (e.g. may be fused together) WARN 2 – indicates that Firing Switch is closed or a short exists in the spool leads

ABORT IF EITHER WARNING IS INDICATED. DO NOT SET SELECTION SWITCH TO 'ARM'.

Typical battery type is 11.4V lithium-ion (e.g. Turnigy nano-tech 450mAh 3S 65C) Typical relay is 12V 8A SPST type (e.g. Digikey p/n PB968-ND) Typical R1 = 1k ohm

Typical flashing LED: Digikey p/n 67-1497-ND

